

Parts List




File No.

Air Conditioner

INDOOR UNIT  
THW2672R  
Made in Japan

Model No.	Prod.Code	Volt-Phase-Hertz
THW2672R	1 854 033 52	208-230-1-60

# THW2672R INDOORUNIT



## ATTENTION !

To ensure correct parts supply, please let us know followings,  
when you make service parts order:

1.Part No. 2.Description 3.Q'ty 4.Volts-Hz-Ph 5.Product Model No.

THW2672R  
INDOOR UNIT

Key No.	Part No.	Description	Q'ty	Reference No.
* 1	623 301 0762	Heat Exch Ass'y	1	854-0-4124-58600
* 2	638 016 3489	Fan Ass'y	4	854-0-2501-24010
3	623 131 4206	Cushion Rubber	2	852-2-2511-15900
* 4	623 191 6783	Fuse MT3 5A	2	1FJ-4-S3A0-03900
5	623 192 0131	Cabinet Ass'y	1	854-9-9536-05298
6	638 016 3595	Suction Grille	1	854-2-1104-16810
7	638 016 3601	Hook Plate	4	854-2-1130-23310
8	638 016 3618	Hook Plate	4	854-2-1130-23410
9	638 016 3625	Frame Filter Ass'y	2	854-0-1302-22810
10	638 016 3632	Side Panel	1	854-2-1102-55310
11	638 016 3649	Side Panel	1	854-2-1102-55410
12	623 192 0155	Ornamental Plate	1	854-2-1308-288H3
13	623 192 0148	Top Panel Ass'y	1	854-9-9536-05297
* 14	638 016 3472	Fan Motor Ass'y SR4X-51A6P	1	854-0-5202-20800
* 15	623 192 1572	Circuit Board Ass'y CR-TH2672	1	854-9-9536-05306
16	623 301 0809	Elec. Wiring Diagram	1	8FA-2-5250-15100
* 17	623 001 1618	Fixed Capacitor UPMDD-440V/1.5MF	1	4-2239-56158
* 18	623 160 8503	Transformer Ass'y ATR-IK244B	1	854-0-5263-18900
* 19	638 016 3441	Terminal Base UKT50-3+15S-2J(A	1	1FJ-4-J3A0-06800
20	623 192 0162	Suction Grille	2	854-2-1104-168H2
* 21	623 160 8527	Thermistor Ass'y PBC-41E-S14	1	854-0-5259-51100
* 22	623 160 1306	Thermistor Ass'y KTEC-35-S6	1	854-0-5259-51000
23	638 016 3793	Insulation	1	854-2-2403-78310
* 24	623 160 8534	Thermistor Ass'y PBC-41E-S14	1	854-0-5259-51200
25	623 184 7209	Cover UKT50-3+15S-2D	1	854-2-5376-00800
26	623 162 8402	Mounting Plate	1	854-2-5312-71001
27	638 016 3670	Front Panel	1	854-2-1101-827H3
* 28	638 008 2063	Synchronized Motor MT8-3C	1	528-0-5000-00303
* 29	623 192 0186	Switch Ass'y SS-01GL13-F	1	854-0-5257-11900
30	623 070 9300	Strainer Ass'y	1	854-0-4522-10400
31	623 192 0179	Packing	2	854-2-2366-47910
32	623 038 3425	Bushing OCB-875	1	851-2-5370-00900
33	638 016 3786	Packing	1	854-2-2366-44210
34	638 015 0922	Shaft	1	854-2-1349-13900
35	638 015 0939	Rod	1	854-2-2329-12600
36	638 015 0946	Cam	1	854-2-2354-11100
37	638 016 3809	Cap	1	854-2-2346-14200
38	638 015 0953	Screw Special	1	854-2-1356-15401
39	638 016 3687	Blower Casing	4	854-2-2506-19010
40	638 016 3694	Blower Casing	4	854-2-2506-18810
41	638 015 0984	Boss Ass'y	1	854-0-2513-11800
42	638 015 0991	Shaft Ass'y	1	854-0-2518-10800
* 43	623 094 4466	Bearing Housing Ass'y	1	852-0-2510-12800
44	638 016 3700	Cover,Elec.Component Box	1	854-2-5304-48500
45	638 016 3717	Elec Component Box Ass'y	1	854-0-5301-73201
46	623 192 0209	Insulation Special	1	854-2-2411-15010
47	623 192 0193	Insulation Special	1	854-2-2411-15210
48	623 054 6073	Insulation Tube	2	852-2-4514-28600
49	623 170 0450	Mounting Plate,Evaporator	1	854-2-2303-30701
50	638 016 3731	Cover, Evaporator	1	854-2-2325-313H2

NOTE: Metal and plastic parts will be supplied basically  
with necessary heat insulation pads or packing.  
Each key number with an asterisk (\*) means the  
recommended service parts.

## ATTENTION !

To ensure correct parts supply, please let us know followings,  
when you make service parts order:

1.Part No. 2.Description 3.Q'ty 4.Volts-Hz-Ph 5.Product Model No.

THW2672R  
INDOOR UNIT

Key No.	Part No.	Description	Q'ty	Reference No.
51	638 015 1066	Partition Plate, Blower	1	854-2-2505-18600
52	638 015 1073	Support Motor Ass'y	1	854-0-2511-24101
53	638 015 1080	Support Fan Motor	1	854-2-2516-29000
54	638 015 1097	Mounting Plate	1	854-2-2361-36901
55	638 015 0618	Hook Plate	1	854-2-1130-23501
56	638 015 0625	Hook Plate	1	854-2-1130-23601
57	623 027 4990	Bushing	1	800-2-5337-17900
58	638 016 3779	Cap	1	854-2-4133-14910
* 59	638 016 3564	Drain Pan Ass'y	1	854-0-2301-482H2
60	623 159 3243	Collar	1	854-2-2535-13600
61	623 159 3588	Support Louver	1	854-2-1111-25001
62	623 192 0223	Air Guide Ass'y	1	854-0-1115-13510
63	623 192 0216	Support Louver	1	854-2-1111-253H2
64	638 016 3663	Side Cover Ass'y, Left	1	854-2-1107-405H2
65	638 016 3656	Side Cover Ass'y, Right	1	854-2-1108-396H2
66	638 015 1141	Wire	1	854-2-1310-27401
67	638 015 1158	Wire	1	854-2-1310-27501
68	623 159 3809	Support Louver	1	854-2-1111-25300
69	623 192 0940	Blade Louver	14	854-2-1110-22610
70	623 192 0933	Mounting Plate	2	854-2-1129-93310
71	623 099 6052	Spacer SPSN-6	1	851-2-5366-04200
72	623 097 1677	Spacer SPLSN-6	4	851-2-5366-03800
* 73	623 301 0786	Remote Control Switch RCS-TM80BG	1	8FA-0-0051-08200

NOTE: Metal and plastic parts will be supplied basically  
with necessary heat insulation pads or packing.  
Each key number with an asterisk (\*) means the  
recommended service parts.

For Parts or Service Contact  
SANYO HVAC SERVICE CENTER  
SANYO Fisher Service Company  
1165 Allgood Road, Suite 22, Marietta, GA 30062 U.S.A.  
300 Applewood Crescent, Concord, Ontario, L4K 5C7, CANADA  
- 4 - 2/07 Printed in Japan